





Fujifilm Endeavor 100ix Camera Battery Replacement

Replace your dying battery to bring the power back to your Fujifilm Endeavor 100ix Camera.

Written By: Eric Nicolai



Step 1 — Battery



- Locate the battery door marked “BATT” on the bottom of the camera.

Step 2




- Pull the battery door tab upward and press in the direction indicated by the arrow on the tab.

Step 3



- Remove the battery by pulling the battery door outward.

Step 4



- Ensure that the clear plastic strip is **below** the new battery.
- Place the new 3 Volt CR2 Lithium Battery in the battery compartment.

After inserting new battery, close the battery door to finish repair.